



# **OWNER'S MANUAL**

**AIR-COOLED DIESEL ENGINE GENERATOR WELDER SET**

**DWG6LE / DWG6LN**



## PREFACE

Thank you for purchasing products from EASTERN TOOLS & EQUIPMENT, INC. We appreciate your business. The following manual is only a guide to assist you and is not a complete or comprehensive manual of all aspects of maintaining and repairing your generator/welder. The equipment you have purchased is a complex piece of machinery. We recommend that that you consult with a dealer if you have doubts or concerns as to your experience or ability to properly maintain or repair your equipment. You will save time and the inconvenience of having to go back to the store if you choose to write or call us concerning missing parts, service questions, operating advice, and/or assembly questions. Our air-cooled diesel welders and generators have some of the following features:

- Lightweight construction
- Air cooled
- Four-stroke diesel internal combustion engine
- Direct fuel injection system
- Recoil starter or an optional electric starter
- Large fuel tank
- Automatic voltage stabilizer
- NFB circuit protector
- AC and DC outputs
- Low oil pressure sensor

The ETQ air-cooled diesel welder and generator set are widely used when electrical power is scarce. Our welders provide a portable mobile solution in supplying power and fabrication needs for field operations during project construction. Some other known applications include pipeline construction and metal welding when electrical power is not available.

This manual will explain how to operate and service your welder and generator set.

If you have any questions or suggestions about this manual, please contact your local dealer or us directly. ***Consumers should notice that this manual might differ slightly from the actual product as more improvements are made to our products. Some of the pictures in this manual may differ slightly from the actual product as well.***


# TABLE OF CONTENTS

	Page number
Overall view of the generator and welder set	4
<b>Chapter 1 Technical Specifications and Data</b>	<b>5</b>
1-1 Technical specifications and data	5
1-2 Basic operating parameters	7
1-3 General dimensions and overview of the generators and welders	7
1-4 Electric wiring diagrams for various models of generators	8
<b>Chapter 2 Operating the Diesel Generator</b>	<b>11</b>
2-1 Main points of safety during operation of the welder generator	11
2-2 Preparation before operation	13
2-3 Checking the operation of the diesel engine	16
2-4 Starting the welder and generator set	16
2-5 Procedures for starting the welder generator set	19
2-6 Proper operation of the welder generator set	21
2-7 Loading	21
2-8 Stopping the generator	24
<b>Chapter 3 Maintenance</b>	<b>25</b>
3-1 Maintenance schedules	25
3-2 Storing for long periods of time	26
<b>Chapter 4 Overhauling and Troubleshooting</b>	<b>28</b>
4-1 Overhauling and troubleshooting procedures	28
4-2 Questions and doubts	28
<b>Chapter 5 Generator Parts Diagrams and Listings</b>	<b>29</b>
<b>Limited Warranty</b>	<b>33</b>
<b>Product Registration Card</b>	<b>34</b>
<b>List for comments from users</b>	<b>36</b>
<b>Appendix</b>	<b>36</b>
1. Attached list of tools fittings, and subassemblies	36
2. Attached technical documents	36

1. Overall view of the DWG6LE series



3. Overall view of the DWG6LE-B series



2. Overall view of the DWG6LE-A



4. Overall view of the DWG6LN series



**CHAPTER 1. TECHNICAL SPECIFICATIONS AND DATA**

**1-1 Technical specifications and data (in SI units)**

Item		Model	DWG6LE	DWG6LN
Electric welding generator data	Generator Technical Data (AC)	Frequency (Hz)	60	60
		Rated power (kW)	2.7	2.7
		Voltage (AC) (V)	120 / 240	120 / 240
		Current (AC) (A)	11	11
		Quantity of phase	Single-phase	
		Power factor (cos φ)	1.0	
	Electric Welding Technical Data (DC)	Electric welding voltage in idle (DC) (V)	55~65	
		Rated current for electric welding (DC) (A)	160~180	
		Working voltage for electric welding (DC) (V)	25-30	
		Electric welding load lasting rate	50%	
		Current range of electric welding (A)	80~210	
	Speed (rpm)		3600	3600
	Excitation		Governable excitation	
	Continuous operation time (Hr. by half load)		Continuous run for 12 hours	
	Frame type		Open frame steel handcart	
	Connection		Rigid connection driven shaft	
	Dry weight (kg)		137	181
Dimensions (LxWxH) (mm)		720x480x645	910x520x740	
Engine	Engine Type		ETQ186FG	
	Output	Continuous (kW)	6.6	6.6
		Maximum (kW)	7.35	7.35
	Bore x Stroke (mm)		86 x 70	
	Displacement (cc)		406	
	Lube-oil capacity (L)		1.65	
	Fuel tank capacity (L)		15	
	Lubricating system		Pressure splash, duplex type lubrication	
	Starting system		Recoil manual start / Electric Start	
Cooling system		Forced air cooling by flywheel fan		

Technical specifications in English units

Item		Model	DWG6LE	DWG6LN
Electric welding generator data	Generator Technical Data (AC)	Frequency (Hz)	60	60
		Rated power (HP)	3.6	3.6
		Voltage (AC) (V)	120 / 240	120 / 240
		Current (AC) (A)	11	11
		Quantity of phase	Single-phase	
		Power factor (cos φ)	1.0	
	Electric Welding Technical Data (DC)	Electric welding voltage in idle (DC) (V)	55~65	
		Rated current for electric welding (DC) (A)	160~180	
		Working voltage for electric welding (DC) (V)	25-30	
		Electric welding load lasting rate	50%	
		Current range of electric welding (A)	80~210	
	Speed (rpm)		3600	3600
	Excitation		Governable excitation	
	Continuous operation time (Hr. by half load)		Continuous run for 12 hours	
	Frame type		Open frame steel handcart	
	Connection		Rigid connection driven shaft	
	Dry weight (lbs)		304	400
Dimensions (LxWxH) (in)		28.35x18.9x25.39	35.82x20.47x29.13	
Engine	Engine Type		ETQ186FG	
	Output	Continuous (HP)	8.85	8.85
		Maximum (HP)	9.85	9.85
	Bore x Stroke (in)		3.39 x 2.76	
	Displacement (cu. in)		24.8	
	Lube-oil capacity (oz)		55.75	
	Fuel tank capacity (US gal)		3.96	
	Lubricating system		Pressure splash, duplex type lubrication	
	Starting system		Recoil manual start / Electric Start	
Cooling system		Forced air cooling by flywheel fan		

## 1-2 Basic operating parameters


1-2.1 Under the given conditions, the generator will output the specified power in the table listed below.

Table 1.


Height above sea level (ft)	Ambient temperature (°F)	RH
0	+60 (+20 °C)	60%
<3280.8 (<1000 m)	41~104 (5-40 °C)	90%

## 1-3 General dimensions and overview of the generators and welders


1-3.1 General dimensions of the DWG7250LE series generators




1-4 Electric wiring diagrams for diesel welder generators









## **CHAPTER 2 OPERATING THE DIESEL GENERATOR**

### **2-1 General main points of safety during operation of the welder and generator set.**

In order to operate the welder and generator set safely, please follow all the instructions provided in this manual carefully. Doing so otherwise may lead to accidents and or equipment damage.

#### **2-1.1 Fire prevention**

The proper fuel for the diesel generator set is light diesel fuel. Do not use gasoline, kerosene and or other fuels other than light diesel fuel. Keep all flammable fuels away from the generator as the generator may spark and ignite these gases. In order to prevent fires from occurring and to provide enough ventilation for people and the machine, keep the diesel generator at least 1.5 meters away from buildings and or other equipment. Always operate your diesel generator on a level site. If the generator is operated on an incline, the lubricating system within the engine will not perform well and may lead to failure of the engine.

#### **2-1.2 Prevention from inhaling exhaust gases**

Never inhale exhaust gases emitted by the engine. The exhaust gases contain toxic carbon monoxide. Never operate your generator in places with poor ventilation. In order to operate this machinery indoors, a suitable ventilation system for the building is required to draw the poisonous exhaust gases out.

#### **2-1.3 Prevention from accidental burns**

Never touch the muffler and its cover when the diesel engine is running. Never touch the muffler and cover after the diesel engine has been used, as the muffler remains hot for a good period of time.


#### **2-1.4 Electric shock and short circuits**

Never touch the generator if the generator is wet. Also never touch the generator if your hand is wet. Never operate your generator if the weather conditions call for any type of precipitation such as rain, snow, or fog. To prevent electrical shocks, the generator should be grounded. Use a lead to connect the grounding end of the generator to the grounding surface of choice. Please refer to Fig. 2-1 and Fig. 2-2 before beginning to use the electric welding generator.

Fig 2-1



Fig 2-2



Note: When connecting devices to the generator, make sure all other devices are rated lower than the generators output. Any generator socket should not be overloaded over its regulated limit

### 2-1.5 Other safety points

Before operating this generator, all operators should have a good knowledge of how to break the circuit if any accidents occur. Also, all operators should be familiar with all the switches and functions of the generator before using this machine. While operating the generator, wear safe shoes and suitable clothes during operation. Always keep children and animals away from the generator.

### 2-1.6 Battery

The electrolytic liquid of the battery contains sulfuric acid. In order to protect your eyes, skin, and clothing, wear protective gear when working with the battery. If you come in contact with the electrolytic liquid, wash it immediately with clean water. Also, if the electrolytic liquid comes in contact with your eyes, see a doctor immediately.


**2-2 Preparation before operation**

**2-2.1 Fuel choices and fuel treatment**

**Fuel tank**



Use only light diesel fuel. The fuel should be filtered clean. Never let dust and water mix with fuel in the fuel tank. Otherwise it will clog the fuel lines and oil nozzles. It may also damage your pressure pump.

Note: It is dangerous to overfill the fuel tank. Never exceed the red piston in the filter.



**Air filter element**

Do not wash the air filter. The element is made of dry material, which does not permit washing. When the output of the diesel engine is bad or the color of the exhaust gas is abnormal, replace the air filter element. Never start the diesel engine without the air filter.



- a. After purchasing fuel, put it into a drum and let it sit for 3-4 days.
- b. 3-4 days later, insert half of the fuel sucker into the drum, (water and impurities stay in the lower portion of the drum)

gearlever



stop


start/run

**Note:**


Never smoke near the opening of the fuel tank. Do not let sparks get near the fuel or fuel tank and do not overfill tank. After filling, tighten the fuel cap.

2-2.2 Filling engine oil

Remove the dipstick from the engine  
 Make sure the generator is on level ground, and fill the engine with 15W40 engine oil. Put the dipstick back into the hole to check the engine oil level.




Capacity	Model	186FG
Litre (British Gal)		1.65 (0.36)




Classification of maintenance for A.P.I. diesel engine  
 The lubricating oil must be CC or CD grade.

Engine oil is the most important factor in determining the life of your generator engine. If you use poor engine oil or if you don't change the oil regularly, the piston and cylinder will wear easily or seize up. Also, the life of the other parts in your engine such as bearings, and other rotating parts will shorten considerably.




Although there is an alarm system to check for low oil pressure, it is always a good idea to check the amount of oil inside the engine. If the oil level is low, fill it before starting the engine. A good time to drain the oil from the engine is when the diesel engine is still hot. If the engine is fully cooled, it is more difficult to drain all the oil out or some impurities will remain in the engine.




Warning: Don't fill engine oil when diesel is operating.

2-2.3 Checking the air filter


- (1) Loosen the butterfly nut, take the cover of the air filter off and take the air filter element out.




Do not use detergent to wash the air filter element. When the performance of the engine decreases or when the color of the exhaust gases is bad, exchange the filter element. Never start the engine without the air filter as foreign objects may enter the intake and damage the engine.



- (2) After replacing the air filter element, replace the cover and tighten the butterfly nut firmly.



2-2.4 Checking the generator welder



*(Note: Only certain welder generator sets have an electric fan incorporated on them.)*

Before starting the generator, make sure the air switch is in the “Off” position. Starting the generator with the switch in the “On” switch is very dangerous.

The generator should be grounded in order to prevent electric shock.


Use dry compressed air (with pressure about 1.96 x 10<sup>5</sup> Pa) to blow the dust out in the electric control cabinet and at the surface of the generator. Check to see how clean the surface of the sliding ring is. Check the pressure of the carbon brush. Also, check whether the position of the carbon brush at the slide rig is correct and the fixture is reliable with a good contact.

According to the electric wiring diagram, check to see whether the connecting wire is correct and the connected place is firm.

Use a 500 M Ω meter to measure the insulation resistance of the electrical part. The resistance should be no less than 5M Ω. When measuring devices, make sure the AVR is turned off. Otherwise, it will burn the AVR. (For the low noise set, the inspection may not be performed).

2-2.5 The fuel and oil in a new engine is drained before sold. Before you start the engine, please fill the fuel tank and engine oil first. Then, check to see if there are air bubbles in the engine. If there are, follow these procedures. Loosen the connecting nut between the oil injection pump and oil pipe. Bleed the air from the system until there are no more bubbles. Then replace the connecting nut and tighten it.

- (3) Check the outer cover of the oil nozzle. Loosen the butterfly nut and open the outer cover.



**2-3 Checking the operation of the diesel engine**

2-3.1 Low-pressure alarm system. ETQ diesel engines have a low-pressure sensor system where if the oil pressure drops too low, the sensor will shut the engine off. The purpose of having this system is to ensure that the engine does not seize up. If there is not enough oil in the engine, the temperature of the oil will be raised too high. On the contrary, if there is too much oil in the engine, the engine oil can slow the engine down considerably.


**2-3.3 Engine break in**

When you purchase a brand new engine, the engine must be properly broken in. The break in period is about 20 hours.

- (1) Avoid overloading the engine when brand new
- (2) Change the engine oil according to specifications. An oil change for a brand new engine is about 20 hours or every month, an older engine, the oil change is about 100 hours or three months.

**2-3.2 How to open the case door/cover**

- (1) Open the case door: turn the handle counterclockwise and open the door. Do these checks daily.




- (2) Loosen the outer cover bolt of the air filter and outer cover of the oil nozzle, and then check the air filter.

**2-4 Starting the welder generator set**

**2-4.1 Manual starting.**


Start the engine in accordance with procedures below:

- (1) Put the fuel switch in the "On" position.






- (2) Turn the handle of the engine to the “RUN” position.



- (3) Pull the recoil starter handle out until you feel resistance. It will reset to its original position automatically. The handle should be reset into its recoil device slowly to prolong the life of the engine starter.

- (4) In cold climate, it is difficult to start the engine. To remedy this, pull the rubber plug out from the rocker of the diesel engine and fill 2 ml of engine oil. Before starting, put the rubber plug back in place. If you don't put the rubber plug back in place, rain, dust and other dirt can enter into the diesel engine. It will cause the parts inside the diesel engine to wear quickly and lead to engine failure.



1. Insert key into ignition and put it in the “off” position.
2. Put the speed handle in the “Run” position.
3. Turn the start switch clockwise to the “START” position; (to set the silent type, first turn it clockwise to the “RUN” (ON) position for 1-2 seconds. The electromagnetic iron will be triggered, now turn it clockwise to the “START” position.
4. After the diesel engine is started, remove your hand from the switch handle; the switch will automatically reset itself to the “ON” position.
5. If the engine is not starting after 10 seconds of cranking, wait about 15 seconds before trying it again. If you crank to long, the voltage of the battery will drop. This can lead to improper ignition. When the diesel engine is operating, let the ignition retain on the “ON” position.



#### 2-4.2 Electric starting


The procedures for preparing to start the engine are the same as the manual starting engine.

**Note:**

If you crank the starter to long, the battery may be drained too much to provide enough energy for proper engine ignition. Also, when the diesel engine is operating, let the key retain in the “ON” position.

## 2-4.3 Battery

**Important Notice:** All of our units come with a dry battery for shipping safety purposes. In order to get your generator started for the first time; the battery must be filled with battery acid which can be purchased at a local automotive supply store and slowly charged (trickle charged) for a day. After charging, the battery may be used. To properly maintain your battery; check the height of the battery acid once a month. If the level of the liquid drops too low, fill it with distilled water until it reaches the high mark. If there is not enough battery acid, then the diesel engine cannot be started. It is important to keep the liquid level between the high and low limits.




high limit of  
liquid level





If the level in the battery is too high, the liquid may flow out and end up on surrounding parts resulting in corrosion of these parts.

**Note:** Avoid too much or too little of battery acid. Check and fill it once a month if necessary.

### 2-5 Procedures for starting the welder generator set

This procedure applies to the L series recoil starting style models.






**2-6 Proper operation of the welder generator set**

- 2-6.1 Operating the diesel engine
1. Pre-heat the diesel engine for 3 minutes under no load conditions.
  2. First check the height of the lubricating oil level, if it is low, refill it. Our diesel engines are equipped with an alarm system that will notify you if the oil pressure is too low. The alarm system will shut down the engine if the oil pressure is too low.
  3. Do not adjust the speed limit regulation bolt or the fuel adjustment bolt. These bolts have been set by the factory already, changing them will affect the properties of the engine performance.



Fuel adjustment bolt      Speed limit bolt



Fuel adjustment bolt      High-pressure fuel pipe nut      Fuel adjustment bolt


2-6.2 Checks during engine operation

1. Check to see if there are abnormal noises.
2. Check to see if the performance is good or bad
3. Check the color of the exhaust gases (whether it is too black or too white). If any of these conditions exist, stop the engine and find the cause of the problem. If no problems are found, please contact your local dealer or our nearest company branch.

**2-7 Loading**

2-7.1 Load conditions

Exert loads in accordance with the specified parameters. For an electric schematic of the welder and generator, please refer to the following one:



2-7.2 Output of electricity

1. Raise the revolutions per minute (turn the speed handle to the max setting) of the generator to get the maximum power out of the generator. If not, the automatic voltage regulator device will excite and doing this for long periods of time will cause the AVR to burn.

- For the rated speed of the generator, please refer to Chapter 1, item 1-1 technical specification and data.
2. Observe the pointer of the voltmeter, it should point to 230 V  $\pm$  5% (50Hz). (For 60 Hz set, it will be 240 V  $\pm$  5%). Meanwhile put the switch in the GEN (generator) position. The AC voltage from the socket of the power supply can be output.
  3. When connecting devices to the generator, make sure to connect these devices in order. Connect the large loads onto the generator first. If everything is functional, smaller loads can then be added. If the generator shuts off, it may be because the load being drawn by all the various devices are too high. In this event, decrease the number of small devices until everything is functional. The total drawn power should not exceed the maximum output power of the generator. Please see Table 1-1 for technical specifications of what the generator can output. In order to reset the generator after overdrawn power, let it sit for several minutes. If the indication of the voltmeter is too high or too low, adjust the speed accordingly. If there are problems, stop the generator immediately and fix the issue.
  4. Switching the switch to GEN outputs electrical power. When doing this, there is enough power for electric welding, but the output current is very small. It can be used for electric welding rods below 3.2mm only. The welder of choice should be below 130A. When electric welding, the load at the output terminal should not be more than 1 kW. In order to guarantee the total load of the set, a general idea is (welder load + generator load).
  5. When choosing the WELD (electric welding), the generator welder will output the necessary power for welding (the socket of the generator has no voltage output). The desired current for various electric welding rods and work can be adjusted through the potentiometer button on the switchboard. After adjusting this to a suitable position, the welding can be carried out. If a smaller current is desired, it can be adjusted by decreasing the speed of the generator. The maximum welding current is 210-220 A. The maximum current cannot be used for long periods of time.
  6. Before operating the generator welder set, the connection between the electric welding cable and terminal should be tight and secure to avoid damaging the terminal caused by a bad contact surface.
  7. During operation, the generator welder should be in

- a place that has very good ventilation. Never cover the engine to solve a ventilation problem, as this will damage your equipment.
8. When the generator welder is used for generating electricity purposes only, the electric welding cable should be disconnected. If the purpose is for electric welding independently, the air switch should be turned off or disconnected to avoid a short circuit at the output end.
  9. A reference for various devices and the power required will be provided in Table 2-1. Also a table for various diameters of welding rods versus how much current is required will be provided in Table 2-2.

**Table 2-1.**

Note: Do not start more than two devices simultaneously. Each device should be started one by one to prevent overloading the generator.

Model \ Load		Incandescent lamphousehold electric appliance	Machines that apply rectifying motor	Machine that apply induced motor (capacitance start type)		
		Projector, electric furnace, etc.	Drill press, Grinder, etc.	Water pump, air compressor, etc.		
				Load	60Hz	50Hz
Single phase synchronous Welder and generator	DWG7250LE	Not exceed 2200/2500W	Not exceed 1000/1200W	400Wor	3	3
	DWG7250LN			250W	4	3

In generator should be running at 3600 revolutions per minute in order to achieve the (60 Hz) frequency. The speed of the engine can be adjusted from the speed governor.

**Table 2-2.**

Dia. of electric welding rod	1.6	2.0	2.5	3.2	4
Power supply for welding	25-40	40-65	50-80	100-130	160-210



**2-7.3 Charging the battery**

1. For the electric starter on the generator welder, the 12V battery is automatically charged through the regulator on the side of the engine when it is running.
2. If the generator is not used for long periods of time, the battery should be disconnected to avoid energy loss from the battery.
3. Do not connect the negative and positive terminals of the battery together at any time. Doing so will damage the battery and cause serious injuries.
4. Do not reverse the polarities when attaching the battery cables to the battery. Doing so will damage both the battery and the electric starter.

- When charging the battery, the battery produces flammable gases. Do not smoke, let flames, and sparks get near the battery while it is charging as this may cause a fire. To avoid sparking while connecting the cables to the battery, first, connect the cables to the battery then to the motor. To disconnect battery cables, first disconnect the motor end of the cable.



**2-8 Stopping the generator**

- Take the electrical load off the generator.
- Turn welder generator air switch off
- Put the speed handle in the “RUN” position and let the engine run for 3 minutes after unloading. Do not stop the diesel engine immediately let it warm down. Stopping the diesel engine suddenly may raise the temperature of the engine abnormally and lock the nozzle and damage the diesel engine.
- Press down on the brake handle
- If equipped with an electric starter, turn the key to the “Off” position
- Put the fuel handle to the “S” position
- Finally, pull slowly on the recoil handle until you feel resistance (this is when the piston is on the compression stroke, where the intake and exhaust valves are closed). What this does is prevent the engine from rusting when not in use.



**Note:**

- If the speed handle is in the “Stop position and the engine is still running, turn the fuel switch to the “OFF” position or loosen the high pressure oil pipe nut. The engine could be stopped more than one-way other than the speed handle way.
- If you cannot stop the engine with a load on it, then remove the load first than stop the engine.





**CHAPTER 3 MAINTENANCE**

**3-1 Maintenance schedules**

Keeping your generator well maintained will prolong the life of your generator. Everything needs to be checked including the diesel engine, welder, generator, control cabinet, and frame. For overhauling procedures, please refer to the instruction manual of the relative subassembly. If you need these manuals, please call our company and we will send you one.

Before starting the maintenance, make sure the diesel engine is off.

Please refer to the Table 3-1 for the proper maintenance schedule.


*Table 3-1. Maintenance schedule for diesel welder generator set*

Interval of maintenance\Item	Everyday	1st month or after 20 hours	3rd month or 100 hours	6th month or 500 hours	Every year or 1000 hours
Check and fill enough fuel	○				
Discharge fuel		○			
Check and fill enough engine oil	○				
Check whether it leaks oil	○				
Check and screw each fastened part	○			● Screw the bolt of cylinder head firmly)	
Exchange engine oil		○ (1st time)	○ (2nd time late)		
Clean filter of engine oil				○ (Exchange)	
Exchange air filter element	If operated at dusty region, the period of maintenance should be shorten)			○ (Exchange)	
Clean filter of fuel				○	● (Exchange)
Check high pressure oil pump				●	
Check nozzle				●	
Check fuel pipe				● (If necessary, exchange it)	
Adjust the gaps of air intake and air exhausted gate		● (1st time)		●	
Grind air intake and air exhausted gate					●
Exchange piston ring					●
Check electrolytic solution of accumulator	(each month)				
Check electric brush and slide ring				●	
Check insulation resistance	The time of stop is over 10 days.			○	

Note: “●” mark indicates that it needs special wrench, please contact with dealer of ETQ.

**3-1.1 Changing the engine oil (every 100 hours)**

Take the oil cover off. Remove the oil drain plug when the diesel engine is still hot. Be careful of hot oil and hot engine as you may get burned. The bolt is located at the bottom of the cylinder. After draining the oil, put the bolt back and tighten it. Then fill with the proper engine oil to the proper level.



**High-pressure fuel pipe bolt**

Oil drain bolt

**3-1.3 Fuel filter maintenance**

1. The fuel filter should be cleaned often to keep the engine running at maximum performance.
2. The recommended time period for cleaning the fuel filter is 6 months or 500 hours of operation.
  - a. To do this, first drain the fuel from the fuel tank.
  - b. Loosen the small screws on the fuel switch and remove the fuel filter from the port. Use diesel fuel to clean the fuel filter. Also, remove the fuel injector and clean the carbon deposit around it. The recommended time period for this is 3 months or 100 hours.

**3-1.2 Air filter maintenance schedule**

1. Clean air-filter every 6 months or 500 hours of operation.
2. If necessary, exchange it.
3. Do not use detergent to clean air filter element.



**Note:**  
Never start the engine without the air filter. This can cause serious damage to the engine if foreign objects enter the intake system. Always change the air filter on time.

**3-1.4 Cylinder head bolt tensions**

The cylinder head bolts should be tightened to specifications please refer to the diesel engine manual for specifications and the special tools required to do this.

**3-1.5 Battery check**

Make sure the electrolytic solution of the battery is full. The engine uses a 12V battery. Due to numerous starting cycles, the electrolytic solution may be used up. Also, before filling, verify that the battery is not damaged in any way. Add distilled water to the battery when filling. Perform checks on the battery once a month.

### 3-2 Storing for long periods of time

If your generator needs to be stored for long periods of time, the following preparations should be made.

1. Start the diesel engine for 3 minutes then stop it.
2. When the engine is still hot, change the engine oil with new engine oil of the proper grade.
3. Pull the rubber plug out of the cylinder head cover and put 2CC of lubricating oil in it, then cover the plughole up again.
4. For manual starting generator welders, press the decompression handle down and pull the recoil handle 2 or 3 times. This pushes the intake out. (Do not start the engine)
5. For electric started generator welders, press the decompression handle down and crank the engine for 2-3 seconds. To do this, put the starter switch in the "Start" position. (Do not start the diesel engine)
6. Finally, pull the recoil starter until you feel resistance; this is when the piston is on the compression stroke where the intake and exhaust valves are closed. Having the intake and exhaust valves closed will prevent rust, as moisture cannot get inside the combustion chamber.
7. Clean the engine and store it in a dry place.

**CHAPTER 4 OVERHAULING AND TROUBLESHOOTING**

**4-1 Overhauling and troubleshooting procedures**

	Causes of malfunction	Remedy
Diesel cannot be started.	Not enough fuel	Add enough fuel
	The switch of fuel is not at "OPEN" position	Turn the switch of fuel to "OPEN" position
	High-pressure pump and nozzle do not inject fuel or the injected amount is less.	Disassemble the nozzle and adjust it at test table.
	Speed control lever is not at "RUN" position.	Turn speed control lever to "RUN" position.
	Check level of lubrication oil.	The standard oil amount of lubricating oil should be between high graduation "H" and low graduation "L"
	It is not quick and powerful to pull reactive starter.	Start diesel engine in accordance with the requirements of "start operation procedures"
	Nozzle exists dirt.	Clean the nozzle.
	Accumulator has not electricity.	Charge the accumulator or exchange it.
Generator cannot generate electricity and has not welding voltage	Master switch (NFB) is not be switched on	Turn master switch handle to "ON" position.
	Carbon brush of generator was worn. The contact is bad.	Exchange the carbon brush.
	The contact of socket is bad.	Adjust the contact feet of socket.
	The rated revolution of engine cannot be reached.	Make it reach to the rated revolution in accordance with the requirements.
	AVR automatic governor is damaged.	Exchange it.
	The potentiometer of current regulation for electric welding is damaged.	Exchange it.

If you are still having trouble, please contact with your nearest dealer or with our company directly if necessary.

**4-2 Questions and doubts**

If you do not understand anything or have any questions, please feel free to contact your local dealer or with our company directly. Below is a list of some information you should have ready before contacting your local dealer or us.

1. Model of diesel engine generator and engine model number.
2. State of residency
3. Number of hours of operating equipment along with the problem that occurred.
4. A detailed condition and time when the problem occurred, in other words, climate and atmosphere

CHAPTER 5 GENERATOR PARTS DIAGRAMS AND LISTINGS

Figure 5-1. Overall view of generator/welder





Table 5-1. Please refer to figure 5-1 for illustration

Number	Part Description	Quantity	Part Number (DWG6LE\DWG6LN)
1	ETQ series diesel engine	1	ETQ6DWGLE1 \ ETQ6DWGLN1
2	Starter Motor	1	ETQ6DWGLE2 \ ETQ6DWGLN2
3	Flywheel generator	1	ETQ6DWGLE3 \ ETQ6DWGLN3
4	Bolt	2	ETQ6DWGLE4 \ ETQ6DWGLN4
5	Voltage Regulator	1	ETQ6DWGLE5 \ ETQ6DWGLN5
6	Battery Cable (red)	1	ETQ6DWGLE6 \ ETQ6DWGLN6
7	Battery Cable (black)	1	ETQ6DWGLE7 \ ETQ6DWGLN7
8	Battery	1	ETQ6DWGLE8 \ ETQ6DWGLN8
9	Oil level sensor	1	ETQ6DWGLE9 \ ETQ6DWGLN9
10	Output panel assembly	1	ETQ6DWGLE10 \ ETQ6DWGLN10
11	Throttle cable	2	ETQ6DWGLE11 \ ETQ6DWGLN11
12	Connector assembly	1	ETQ6DWGLE12 \ ETQ6DWGLN12
13	Capacitor	1	ETQ6DWGLE13 \ ETQ6DWGLN13
14	Bolt	2	ETQ6DWGLE14 \ ETQ6DWGLN14
15	Voltage Regulator Bracket	1	ETQ6DWGLE15 \ ETQ6DWGLN15
16	Bolt	2	ETQ6DWGLE16 \ ETQ6DWGLN16


**Figure 5-2. Framework exploded view**



**Table 5-2.** Please refer to figure 5-2.

Number	Part Description	Quantity	Part Number (DWG6LE\DWG6LN N)
1	M6 x 25 Bolt	4	ETQ6DWGLE17 \ ETQ6DWGLN17
2	M6 Flat washer	4	ETQ6DWGLE18 \ ETQ6DWGLN18
3	Shock absorber	4	ETQ6DWGLE19 \ ETQ6DWGLN19
4	Washer	4	ETQ6DWGLE20 \ ETQ6DWGLN20
5	M6 Nut	4	ETQ6DWGLE21 \ ETQ6DWGLN21
6	Engine cover	1	ETQ6DWGLE22 \ ETQ6DWGLN22
7	Rubber cover	1	ETQ6DWGLE23 \ ETQ6DWGLN23
8	Handrail	1	ETQ6DWGLE24 \ ETQ6DWGLN24
9	M8 x 65 Bolt	4	ETQ6DWGLE25 \ ETQ6DWGLN25
10	Plastic gasket	4	ETQ6DWGLE26 \ ETQ6DWGLN26
11	Flat washer M8	4	ETQ6DWGLE27 \ ETQ6DWGLN27
12	Spring washer	4	ETQ6DWGLE28 \ ETQ6DWGLN28
13	M8 Nut	4	ETQ6DWGLE29 \ ETQ6DWGLN29
14	Battery tie down	1	ETQ6DWGLE30 \ ETQ6DWGLN30
15	M6 Nut	2	ETQ6DWGLE31 \ ETQ6DWGLN31
16	Tie down hooks	2	ETQ6DWGLE32 \ ETQ6DWGLN32
17	Battery	1	ETQ6DWGLE33 \ ETQ6DWGLN33
18	M8x12 bolts	2	ETQ6DWGLE34 \ ETQ6DWGLN34
19	Rubber absorber	1	ETQ6DWGLE35 \ ETQ6DWGLN35
20	Motor mount	1	ETQ6DWGLE36 \ ETQ6DWGLN36
21	Battery tray	1	ETQ6DWGLE37 \ ETQ6DWGLN37
22	M6 Nut	1	ETQ6DWGLE38 \ ETQ6DWGLN38
23	Spring washer 6	1	ETQ6DWGLE39 \ ETQ6DWGLN39
24	M6 x 35 Bolt	1	ETQ6DWGLE40 \ ETQ6DWGLN40
25	M10 Nut	2	ETQ6DWGLE41 \ ETQ6DWGLN41
26	Spring washer 10	2	ETQ6DWGLE42 \ ETQ6DWGLN42
27	Flat washer 10	2	ETQ6DWGLE43 \ ETQ6DWGLN43
28	M10 x 20	2	ETQ6DWGLE44 \ ETQ6DWGLN44
29	Bracket	1	ETQ6DWGLE45 \ ETQ6DWGLN45
30	M10 Nut	4	ETQ6DWGLE46 \ ETQ6DWGLN46
31	Spring washer 10	4	ETQ6DWGLE47 \ ETQ6DWGLN47
32	Flat washer 10	4	ETQ6DWGLE48 \ ETQ6DWGLN48
33	Rubber mounts	4	ETQ6DWGLE49 \ ETQ6DWGLN49
34	Flat washer 10	4	ETQ6DWGLE50 \ ETQ6DWGLN50
35	Spring washer 10	4	ETQ6DWGLE51 \ ETQ6DWGLN51
36	M10 Nut	4	ETQ6DWGLE52 \ ETQ6DWGLN52
37	Axle	1	ETQ6DWGLE53 \ ETQ6DWGLN53
38	M6 Nut	4	ETQ6DWGLE54 \ ETQ6DWGLN54
39	U bolt	2	ETQ6DWGLE55 \ ETQ6DWGLN55
40	Flat washer 20	2	ETQ6DWGLE56 \ ETQ6DWGLN56
41	Split pin 32 x 32	2	ETQ6DWGLE57 \ ETQ6DWGLN57
42	Wheel	2	ETQ6DWGLE58 \ ETQ6DWGLN58
43	Solenoid cable bolts	2	ETQ6DWGLE59 \ ETQ6DWGLN59
44	Solenoid	1	ETQ6DWGLE60 \ ETQ6DWGLN60
45	Solenoid bracket	1	ETQ6DWGLE61 \ ETQ6DWGLN61
46	Bolts	4	ETQ6DWGLE62 \ ETQ6DWGLN62
47	Throttle cable	1	ETQ6DWGLE63 \ ETQ6DWGLN63
48	M8 x 40 Bolt	4	ETQ6DWGLE64 \ ETQ6DWGLN64
49	M8 Nut	4	ETQ6DWGLE65 \ ETQ6DWGLN65
50	Bracket	2	ETQ6DWGLE66 \ ETQ6DWGLN66
51	Bracket	1	ETQ6DWGLE67 \ ETQ6DWGLN67
52	Rubber insulator	2	ETQ6DWGLE68 \ ETQ6DWGLN68

**Figure 5-3. Electric panel parts drawing**




**Table 5-3. Please refer to Figure 5-3**

Number	Part Description	Quantity	Part Number (DWG6LE\DWG6LN)
1	Positive DC port	1	ETQ6DWGLE69 \ ETQ6DWGLN69
2	Negative DC port	1	ETQ6DWGLE70 \ ETQ6DWGLN70
3	Grounded bolt	1	ETQ6DWGLE71 \ ETQ6DWGLN71
4	Bolt	2	ETQ6DWGLE72 \ ETQ6DWGLN72
5	Large Nut	1	ETQ6DWGLE73 \ ETQ6DWGLN73
6	Bolt	2	ETQ6DWGLE74 \ ETQ6DWGLN74
7	Bolt	2	ETQ6DWGLE75 \ ETQ6DWGLN75
8	Large Nut	1	ETQ6DWGLE76 \ ETQ6DWGLN76
9	Current Adjusting Switch	1	ETQ6DWGLE77 \ ETQ6DWGLN77
10	3 prong Socket	2	ETQ6DWGLE78 \ ETQ6DWGLN78
11	Bolt	6	ETQ6DWGLE79 \ ETQ6DWGLN79
12	Electric panel bolt	6	ETQ6DWGLE80 \ ETQ6DWGLN80
13	Electric Panel	1	ETQ6DWGLE81 \ ETQ6DWGLN81
14	Starter switch	1	ETQ6DWGLE82 \ ETQ6DWGLN82
15	Large nut	6	ETQ6DWGLE83 \ ETQ6DWGLN83
16	Oil alert lamp	1	ETQ6DWGLE84 \ ETQ6DWGLN84
17	Hour meter	1	ETQ6DWGLE85 \ ETQ6DWGLN85
18	Hour meter bolts	2	ETQ6DWGLE86 \ ETQ6DWGLN86
19	DC Fuse	1	ETQ6DWGLE87 \ ETQ6DWGLN87
20	Voltmeter	1	ETQ6DWGLE88 \ ETQ6DWGLN88
21	Nut	2	ETQ6DWGLE89 \ ETQ6DWGLN89
22	4 prong socket	1	ETQ6DWGLE90 \ ETQ6DWGLN90
23	Breaker bracket	1	ETQ6DWGLE91 \ ETQ6DWGLN91
24	Nut	2	ETQ6DWGLE92 \ ETQ6DWGLN92
25	Breaker	1	ETQ6DWGLE93 \ ETQ6DWGLN93
26	Wiring harness	1	ETQ6DWGLE94 \ ETQ6DWGLN94
27	Electrical box	1	ETQ6DWGLE95 \ ETQ6DWGLN95




Figure 5-4. Generator head assembly



**Table 5-4.** Please refer to figure 5-4

Number	Part Description	Quantity	Part Number (DWG6LE\DWG6LN)
1	Front end cover	1	ETQ6DWGLE96 \ ETQ6DWGLN96
2	Diode	2	ETQ6DWGLE97 \ ETQ6DWGLN97
3	M4 x 8 Bolt	2	ETQ6DWGLE98 \ ETQ6DWGLN98
4	Fan Blade	1	ETQ6DWGLE99 \ ETQ6DWGLN99
5	Bearing	1	ETQ6DWGLE100 \ ETQ6DWGLN100
6	Rotor Unit	1	ETQ6DWGLE101 \ ETQ6DWGLN101
7	Center bolt	1	ETQ6DWGLE102 \ ETQ6DWGLN102
8	Motor cover	1	ETQ6DWGLE103 \ ETQ6DWGLN103
9	Stator	1	ETQ6DWGLE104 \ ETQ6DWGLN104
10	Long bolt	4	ETQ6DWGLE105 \ ETQ6DWGLN105
11	Capacitor	1	ETQ6DWGLE106 \ ETQ6DWGLN106
12	Wiring Seat	1	ETQ6DWGLE107 \ ETQ6DWGLN107
13	M5 x 15 Bolt	6	ETQ6DWGLE108 \ ETQ6DWGLN108
14	Stator Unit	1	ETQ6DWGLE109 \ ETQ6DWGLN109
15	Dust Cover	1	ETQ6DWGLE110 \ ETQ6DWGLN110

**Figure 5-5. Fuel system components**



**Table 5-5. Please refer to figure 5-5.**

Number	Part Description	Quantity	Part Number (DWG6LE\DWG6LN)
1	Fuel Cap	1	ETQ6DWGLE111 \ ETQ6DWGLN111
2	Seal	1	ETQ6DWGLE112 \ ETQ6DWGLN112
3	Filtering cup	1	ETQ6DWGLE113 \ ETQ6DWGLN113
4	M5 x 10 screw	2	ETQ6DWGLE114 \ ETQ6DWGLN114
5	Fuel lever indicator	1	ETQ6DWGLE115 \ ETQ6DWGLN115
6	M6 x 25 Bolt	4	ETQ6DWGLE116 \ ETQ6DWGLN116
7	Large flat washer 6	4	ETQ6DWGLE117 \ ETQ6DWGLN117
8	Fuel tank lining	4	ETQ6DWGLE118 \ ETQ6DWGLN118
9	Shock absorbing gasket	4	ETQ6DWGLE119 \ ETQ6DWGLN119
10	Fuel tank	1	ETQ6DWGLE120 \ ETQ6DWGLN120
11	M6 Nut	4	ETQ6DWGLE121 \ ETQ6DWGLN121
12	O ring seal	1	ETQ6DWGLE122 \ ETQ6DWGLN122
13	Fuel tank filter	1	ETQ6DWGLE123 \ ETQ6DWGLN123
14	O ring gasket	1	ETQ6DWGLE124 \ ETQ6DWGLN124
15	Fuel filter cover	1	ETQ6DWGLE125 \ ETQ6DWGLN125
16	Cover	1	ETQ6DWGLE126 \ ETQ6DWGLN126
17	Wing nut	1	ETQ6DWGLE127 \ ETQ6DWGLN127
18	Fuel line	2	ETQ6DWGLE128 \ ETQ6DWGLN128
19	Fuel inlet pipe	1	ETQ6DWGLE129 \ ETQ6DWGLN129
20	High pressure fuel pump	1	ETQ6DWGLE130 \ ETQ6DWGLN130
21	High pressure fuel pipe	1	ETQ6DWGLE131 \ ETQ6DWGLN131
22	Fuel injector	1	ETQ6DWGLE132 \ ETQ6DWGLN132
23	Overfill tube	2	ETQ6DWGLE133 \ ETQ6DWGLN133
24	Fuel overfill pipe	1	ETQ6DWGLE134 \ ETQ6DWGLN134

**LIMITED WARRANTY**

Eastern Tools & Equipment, Inc. will repair or replace, free of charge, any part or parts of the generator that are defective in material or workmanship or both. Transportation charges on parts submitted for repair or replacement under this Warranty must be borne by purchaser. This warranty is effective for the time period and subject to the conditions provided for in this policy. For warranty service, find the nearest Authorized Service Dealer by contacting the place of purchase or Eastern Tools & Equipment, Inc. **THERE IS NO OTHER EXPRESSED WARRANTY. IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO ONE YEAR FROM PURCHASE, OR TO THE EXTENT PERMITTED BY LAW ANY AND ALL IMPLIED WARRANTIES ARE EXCLUDED. LIABILITY FOR CONSEQUENTIAL DAMAGES UNDER ANY AND ALL WARRANTIES ARE EXCLUDED TO THE EXTENT EXCLUSION IS PERMITTED BY LAW.** Some states do not allow limitations on how long an implied warranty lasts, and some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation and exclusion may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

**Eastern Tools & Equipment, Inc.**

**WARRANTY PERIOD\*\*\***

ENGINES	WITHIN U.S.A AND CANADA		OUTSIDE U.S.A. AND CANADA	
	CONSUMER USE	COMMERCIAL USA	CONSUMER USE	COMMERCIAL USE
DIESEL GENERATOR	1 year or 1000 hours	1 year or 1000 hours	1 year or 1000 hours	1 year or 1000 hours

\* The warranty period begins on the date of purchase by the first retail consumer or commercial end user, and continues for the period of time stated in the table above. "Consumer use" means personal residential household use by a retail consumer. "Commercial use" means all other uses, including use for commercial, income producing or rental purposes. Once the engine has experienced commercial use, it shall thereafter be considered as a commercial use engine for purposes of this warranty. **Engines used in competitive racing or on commercial or rental tracks are not warranted.**

\*\*\* A two-year or 1,500 hour warranty applies to the emission control system on engines certified by EPA and CARB

**IMPORTANT**  
**"WARRANTY REGISTRATION IS NECESSARY TO OBTAIN LIMITED WARRANTY ON EASTERN TOOLS & EQUIPMENT, INC., ENGINES. THE WARRANTY REGISTRATION CARD MUST BE RETURNED WITHIN 15 DAYS OF ORIGINAL PURCHASE FOR LIMITED WARRANTY TO BE VALID."**

**About Your Product Warranty**

Eastern Tools & Equipment, Inc. welcomes warranty repair and apologizes to you for being inconvenienced. Any Authorized Service Dealer may perform warranty repairs. Most warranty repairs are handled routinely, but sometimes warranty service may be inappropriate. For example, warranty would not apply if an engine is damaged because of misuse, lack of routine maintenance, shipping, handling, warehousing and improper installation. Similarly, warranty is void if the serial number on the engine has been removed or if the engine has been altered or modified. If a customer differs with the decision of the Service Dealer, an investigation will be made to determine whether the warranty applies. Ask the Service Dealer to submit all supporting facts to his Distributor or the factory for review. If the distributor or the factory decides that the claim is justified, the customer will be fully reimbursed for those items that are defective. To avoid misunderstanding, which might occur between the customer and the dealer, listed below are some of the causes of engine failure that the warranty does not cover.

**Normal wear:**

Engines and generators, like all mechanical devices, need periodic parts service and replacement to perform well. Warranty will not cover repair when normal use has exhausted the life of a part of an engine.

**Improper maintenance:**

The life of an engine or your equipment depends upon the conditions under which it operates, and the care it receives. Some applications, such as tillers, pumps, and rotary movers, are very often used in dusty or dirty conditions, which can cause what appears to be premature wear. Such wear, when caused by dirt, dust, spark pug cleaning grit, or other abrasive material that has entered the engine because of improper maintenance is not covered by warranty.

**This warranty covers engine related defective material and/or workmanship only, and not replacement or refund of the equipment to which the engine may be mounted. Nor does the warranty extend to repairs required because of:**

1. PROBLEMS CAUSED BY PARTS THAT ARE NOT ORIGINAL EASTERN TOOLS & EQUIPMENT, INC., PARTS.
2. Equipment controls or installations that prevent starting, cause unsatisfactory engine performance, or shorten engine life. (Contact equipment manufacturer.)
3. Leaking carburetors, clogged fuel pipes, sticking valves, or other damage, caused by using contaminated or stale fuel. (Use clean, fresh, lead-free gasoline.)
4. Parts which are scored or broken because an engine was operated with insufficient or contaminated lubricating oil, or an incorrect grade of lubricating oil (check oil level daily or after every 8 hours of operation. Refill when necessary and change at recommended intervals.) Engine damage may occur if oil level is not properly maintained. Read Operating & Maintenance Instructions.
5. Repair or adjustment of associated parts or assemblies such as clutches, transmissions, remote controls, etc., which are not manufactured by Eastern Tools & Equipment, Inc.
6. Damage or wear to parts caused by dirt, which entered the engine because of improper air cleaner maintenance, re-assembly, or use of a non-original air cleaner element or cartridge. Read Operating & Maintenance Instructions.
7. Parts damaged by over-speeding, or overheating caused by grass, debris, or dirt, which plugs or clogs the cooling fins, or flywheel area, or damage caused by operating the engine in a confined area without sufficient ventilation.
8. Engine or equipment parts broken by excessive vibration caused by a loose cutter blades unbalanced blades or loose or unbalanced impellers, improper attachment of equipment to engine crankshaft, over-speeding or other abuse in operation.
9. A bent or broken crankshaft, caused by striking a solid object with the cutter blade of a rotary lawn mower, or excessive v-belt tightness.
10. Routine tune-up or adjustment of the engine.
11. Engine or engine component failure, i.e., combustion chamber, valves, valve seats, valve guides, or burned starter motor winding, caused by the use of alternate fuels such as, liquefied petroleum, natural gas, altered gasoline's, etc.

**Warranty is available only through service dealers, which have been authorized by Eastern Tools & Equipment, Inc. Contact place of purchase or Eastern Tools & Equipment, Inc. for Service Dealer near you.**

**CALIFORNIA & USEPA EMISSION CONTROL WARRANTY STATEMENT**

The U.S. Environmental Protection Agency (EPA), the California Air Resources Board (CARB) and Eastern Tools & Equipment, Inc. are pleased to explain the Federal and California Emission Control System Warranty on your 2003 small off-road engine. In California, new small off-road engines must be designed, built and equipped to meet the State's stringent anti-smog standards. Eastern Tools & Equipment, Inc. must warrant the emission control system on your small off-road engine for the periods of time listed above provided there has been no abuse, neglect or improper maintenance of your small off-road engine.

Your emission control system may include parts such as the carburetor, or fuel-injection system, the ignition system and catalytic converter. Also included may be hoses, belts, connectors and other emission-related assemblies.

Where a warrantable condition exists, Eastern Tools & Equipment, Inc. will repair your small off-road engine at no cost to you including diagnosis, parts and labor.

<b>PRODUCT REGISTRATION CARD</b>			
<i>For more efficient customer service, please fill out the information below and mail to Eastern Tools &amp; Equipment, Inc. Product Warranty and Registration Division, 12220 Rivera Rd, suite B; Whittier, CA 90606</i>			
Model No. _____	Engine Serial No. _____	Purchase Date ____/____/____	
<b>Purchased from:</b> <input type="checkbox"/> Retail location <input type="checkbox"/> Private Consumer <input type="checkbox"/> Other _____			
Name _____			
Location Address _____			
Telephone w/ area code _____		Purchase Price _____	
<b>Purchased:</b> <input type="checkbox"/> NEW or <input type="checkbox"/> USED			
<b>Consumer information:</b>			
Name _____		Telephone w/ area code _____	
Street Address _____			
City _____	State _____	Zip Code _____	Suite or Apt No. _____
Province or Country _____			
Are you a: <input type="checkbox"/> Business or <input type="checkbox"/> Residence			
<b>Product Usage Information:</b>			
How often will you use this product? <input type="checkbox"/> Everyday <input type="checkbox"/> Periodically <input type="checkbox"/> Emergency use only			
<input type="checkbox"/> Other _____			
<b>What type of application will you use this product in?</b>			
<input type="checkbox"/> Heavy Commercial	<input type="checkbox"/> Moderate Commercial	<input type="checkbox"/> Light Commercial	<input type="checkbox"/> Tradeshow
<input type="checkbox"/> Heavy Residential	<input type="checkbox"/> Moderate Residential	<input type="checkbox"/> Light Residential	<input type="checkbox"/> Camping, backpacking
<input type="checkbox"/> Other _____			
<b>IMPORTANT INFORMATION:</b>			
It is critical to your warranty that the original point of sales receipt be retained by current consumer, and in order to comply with Eastern Tools & Equipment Product Warranty Statement you must return this registration card within 15 days of original purchase. Product warranty is valid from original date of purchase.			

**OWNER'S WARRANTY RESPONSIBILITIES**

As the small off-road engine owner, you are responsible for the performance of the required maintenance listed in your Owner's Manual. Eastern Tools & Equipment, Inc. recommends that you retain all receipts covering maintenance on your small off-road engine, but Eastern Tools & Equipment, Inc. cannot deny warranty solely for the lack of receipts or for your failure to ensure the performance of all scheduled maintenance.

As the small off-road engine owner, you should, however, be aware that Eastern Tools & Equipment, Inc. may deny you warranty coverage if your small off-road engine or a part thereof has failed due to abuse, neglect, improper maintenance or unapproved modifications.

You are responsible for presenting your small off-road engine to Eastern Tools & Equipment, Inc. distribution center as soon as a problem exists. The warranty repairs should be completed in a reasonable amount of time, not to exceed 30 days.

If you have any questions regarding your warranty rights and responsibilities or to request warranty service you should contact either the place of purchase or Eastern Tools & Equipment, Inc., c/o Service Manager, Engine and Equipment Service Division, 12220 Rivera Road, Suite-B; Whittier, California 90606. Telephone 1-562-698-7500, or contact Eastern Tools & Equipment, Inc. through the Internet at <http://www.easterntools.com>

**IMPORTANT NOTE:**

This warranty statement explains your rights and obligations under the Emission Control System Warranty (ECS Warranty), which is provided to you by Eastern Tools & Equipment, Inc. pursuant to California law. Eastern Tools & Equipment, Inc. also provides to original purchasers of new Eastern Tools & Equipment, Inc engines. Eastern Tools & Equipment, Inc. Limited Warranties for New engines & other Equipment associated with the engine (Eastern Tools & Equipment, Inc. Products Warranty), which is enclosed with all New Eastern Tools & Equipment, Inc. engines and products on a separate sheet. The ECS Warranty applies only to the emission control system of your new engine. To the extent that there is any conflict in terms between the ECS Warranty and the Eastern Tools & Equipment, Inc., Warranty, the ECS Warranty shall apply except in any circumstances in which the Eastern Tools & Equipment, Inc. Product Warranty may provide a longer warranty period. Both the ECS Warranty and the Eastern Tools & Equipment, Inc. product Warranty describe important rights and obligations with respect to your new engine.

Eastern Tools & Equipment, Inc. at its location in Whittier, California can perform warranty service or any authorized service dealer near you. At the time of requesting warranty service, evidence must be presented of the date of sale to the original purchaser. The purchaser shall pay any charges for transporting the products to and from the place where the inspection and/or warranty work is performed. The purchaser shall be responsible for any damage or loss incurred in connection with the transportation of any engine or any part(s) thereof submitted for inspection and/or warranty work.

If you have any questions regarding your warranty rights and responsibilities, you should contact eastern Tools & Equipment, Inc. at 1-562-320-0231.

**List for comments from users**

		Date of Manufacture	
Name of user		Model Number	
Address of user		Occupation	
Place of purchase			
Packaging conditions			
Operating conditions			
Parts Conditions			
Malfunction problem			
Opinions or suggestions			

Note: Please mail the above card to: **Eastern Tools & Equipment, Inc.**  
**12220 Rivera Rd, Suite B**  
**Whittier, CA 90606**

**Appendix:**

## 1. Attached list of tools, fittings, and subassemblies

Order No.	Name	Qty	Remarks
1	Air-cooled diesel welder and generator set	1	
2	Kit	1	
3	Plastic cover	1	
4	Plug and power supply	1	

## 2. Attached technical documents

Order No.	Name	Qty	Remarks
1	Air cooled diesel welder and generator manual	1	
2	Diesel engine instruction manual	1	
3	Diesel engine parts listing	1	
4	Certificate of Quality	1	
5	Packing List	1	

**EASTERN TOOLS & EQUIPMENT, INC.**

**TEL: 1-626-960-6299**

**FAX: 1-626-960-6244**

**WEB SITE.<http://easterntools.com>**